




SMARTKEEPER® Quality Assurance

SMARTKEEPER Quality Assurance Coverage

- In the event of a manufacturing defect, the quality is guaranteed for one year after the original date of purchase.
- Make sure that the rubber tips (6 places) on the Left and Right Monitor Holders are installed. If the tips are missing, contact customer service within 7 days after purchase for an exchange.
- In the event of a manufacturing defect, contact customer service as soon as possible. If the client continues to use the defective product without contacting customer service, the manufacturer is not responsible for any problems (display panel damage, laptop body damage, scratches, dents, etc.) that occur while using the product.
- Be sure to read the precautions specified in the user's manual. The manufacturer is not responsible for any problems or damage that is caused by not following the precautions.
- The manufacturer is not responsible for any issues caused by consumer negligence (dropping, forced detachment attempt, throwing, etc.).
- It is impossible to reset the PIN if you lose/forget your pin. Be careful not to lose/forget the PIN.
- The manufacturer is not responsible for data loss due to the installation and use of storage devices that are not certified this product.
- The manufacturer is not responsible for data loss while using storage devices.
- Proof of purchase is required for all exchanges due to manufacturing defect.
- Please contact **COMXI Customer Service** at **1.804.299.5234**, should you have any questions or concerns.

Product Information




Product	Laptop Hub Package
Model No.	LLD02P
Manufacturer	COMXI Co., Ltd.
Country of Manufacture	Republic of Korea
Date of Purchase	20
Warranty	1 Year from the date of purchase
Customer Service	1.804.299.5234




Uninstall


Laptop Lock Plus




- ① Slide the Hub Housing Cover in the direction of the arrow to open it.




- ② Input the 4 digit PIN to unlock the Combination Lock.




- ③ Pull the Lock Ring out and turn it clockwise 90° to remove the wire from the Lock Ring.




- ④ Hold the main body and slide the Latch Bar out. Remove the laptop from Laptop Lock Plus.



- ⑤ Slide the Latch Bar back in.




- ⑥ Rotate the Lock Ring back counterclockwise 90°. Release the Lock Ring.




- ⑦ Lower the monitor holders to the base and turn the base in toward the main body. Slide the Hub Housing Cover in the direction of the arrow.

Assembling and Disassembling The Hub


Laptop Hub Package




- ① Slide out the Side Fixture Cover and remove it.




- ② Pull out the Side Fixture Ring to remove it.




- ③ Slide the Hub Housing Cover and open it.




- ④ Remove the Wire Slot Cover.



- ⑤ Install the Multi Hub.



- ⑥ Slide the Hub Housing Cover and close it.




- ⑦ Install the Wire Slot Cover by inverting it up and down.

① Please Note

- Disassembly is the reverse order of assembly.


Laptop Hub Package

User Guide



Laptop Hub Package

Anti-Theft device for laptop computers (including slim models) with or without built-in lock slots.



Components



Caution




- Compatible with laptop computers (including slim models) with or without built-in lock slots.
- NOT compatible while a laptop computer is in clamshell mode.

Laptop Lock Plus	Width x Length x Depth: 273.0 x 76.0 x 24.0 mm Weight: 395g Security Cable : Thickness x Length : 4mm x 2M
Multi Hub	Width x Length x Depth: 140.0 x 18.2x 40 mm Weight: 115g Security Cable : 20 cm


Ready to Install

Laptop Lock Plus




Caution

- Make sure that the **rubber tips (6 places)** on the Left and Right Monitor Holders are installed.
- If the tips are missing, contact customer service **within 7 days** after purchase for an exchange.
- In the event of a manufacturing defect, contact customer service as soon as possible. If the client continues to use the defective product without contacting customer service, **the manufacturer is not responsible for any problems** (display panel damage, laptop body damage, scratches, dents, etc.) that occur while using the product.




Installation

Laptop Lock Plus




Caution

- In the event the Lock Ring is turned 180°, Do NOT move the number dials to prevent accidental resetting of the PIN.
- If the number dials are turned by accident and the PIN changes, **You may not be able to reset the PIN.** Make sure to turn the Lock Ring **ONLY 90°**.



Pin Reset Possible
Lock Ring Turned 180°



4

Pull out the Latch Bar to secure Laptop.

5

Lift the Left Monitor Holder to slide in the Laptop Monitor.

6

Slide the Latch Bar inward toward the laptop.

7

Lift the Right Monitor Holder and slide the Latch Bar until it is flush against the Laptop.

8

Attach the Security Cable according to the diagram unto a fixture such as a leg of a desk.

9

Hook the other end of the Security Cable on the Lock Ring.

10


Rotate the Lock Ring back counterclockwise 90° and turn the number dials to lock.

11


Slide the Hub Housing Cover in the direction of the arrow to conceal the Combination Lock.

Caution

- Before/after sliding the Hub Housing Cover, push the Left and Right Bases inward toward each other to better secure the Laptop Lock Plus.




- Once the Laptop Lock Plus is installed, Laptop monitors will **not completely close or flip 360°**. Depending on the models, Laptop monitors can be adjusted between **50° to 160°**.



- Should one attempt to forcibly close or open the Laptop monitor beyond the acceptable range, the Laptop monitor may be damaged. **The manufacturer is not responsible for such damages caused by consumer negligence.**

PIN Reset

Laptop Lock Plus




1

Pull the Lock Ring out in the direction of the arrow.

2

Turn the Lock Ring it clockwise 180°. Release the Lock Ring.




3

Turn the 4 number dials to the desired PIN.

Caution

- Push the Lock Ring inward completely** to reset the PIN.



- While resetting the PIN, make sure the new numbers line up perfectly to the arrows on the Combination Lock.

4

Pull out and turn the Lock Ring counterclockwise 180°.

5

Release the Lock Ring to complete PIN reset.

Caution

- Initial PIN is "0000". It is **impossible to reset the PIN** if you lose/forget your pin. Be careful not to lose/forget the PIN.